

REPEATER SETUP INSTRUCTIONS



(1)



(2)



(3)

- 1) Open blue crate & remove antenna mast and antenna. Then rotate the curved legs until they ‘snap’ into place.**
- 2) Build the antenna mast by sliding each section together like a tent-pole. Then screw the antenna onto the brass fitting at the top of the pole. DO NOT OVER TIGHTEN! Once complete flip the repeater onto it’s legs.**
- 3) Slide the assembled antenna mast into the receptor on the bottom of the blue crate until it reaches the black line found on the mast. Plug into a 110V AC outlet and the repeater is operational.**